

# Anti-Rotation T Pull & Knob

## Fitting Instructions

### Kit Contents

Component	Quantity
T Pull or Knob	1
End Cap Fitting	1
<b>Screw A</b> 15mm M4 Fixing (For doors between 18mm and 21mm thick)	1
<b>Screw B</b> 18mm M4 Fixing (For doors between 22mm and 24mm thick)	1
<b>Screw C</b> 16mm Wood Screws	3

### Instructions

**Step 1:** Mark the desired position of the handle on the cupboard door.

**Step 2:** Drill a 10mm diameter hole. Please ensure hole is perpendicular to the cupboard door.

**Step 3:** Push the end cap fitting into the hole from the rear of the door as shown in diagram 1.

**Step 4:** Locate the handle into the hole from the front of the door, ensuring it aligns with the end cap fitting (as shown in diagram 1).

**Step 5:** Using a screwdriver, lightly secure the handle using screw A or screw B (depending on your cupboard door thickness).

**Step 6:**

- a) T pull installation - Align the handle in the horizontal or vertical position and fully tighten screw A/B.
- b) Knob installation - Align the pattern in the horizontal or vertical position and fully tighten screw A/B.

**Step 7:** Using a screwdriver, secure the handle into position using 3 x screw C.

### Diagram 1

Anti-rotation t pull used for illustration purposes. Please repeat steps for anti-rotation knob installations.



**Please note:** Anti-rotation mechanism will prevent product from turning under normal use.